



# BUCKLE THREADING INSTRUCTIONS


- 1** Feed Narrostrap under the load to be secured before threading the buckle. Form a loop at one end of the Narrostrap. The buckle must be held such that the legs are facing the top and the right hand side.




- 2** Insert the loop through the centre of the buckle from the bottom of the buckle.




- 3** Thread the loop over the rear buckle leg and pull through.




- 4** Tighten the Narrostrap by pulling the strap (not the cut end!).




- 5** Ensure that there is no slack under the load and then form a loop on the other end of the Narrostrap.




- 6** Insert this loop through the centre of the buckle from the bottom of the buckle.



- 7** Thread this loop over the front buckle leg and pull through.



- 8** Now pull the the tail end of the Narrostrap to complete the threading and to remove any remaining slack under the load.



*Narrowtex recommends the use of high quality Narrostrap Phosphate buckles in conjunction with Narrostrap polyester woven strapping*



Unit 2, 63 Parramatta Road, Underwood, Qld, 4119 • P.O.Box 966, Slacks Creek, Queensland, 4127, Australia  
Tel: (07)32904300 • Fax: (07)32904399 • Mobile: 0403755652 • Email: [info@narrowtex.com.au](mailto:info@narrowtex.com.au)

[www.narrowtex.com.au](http://www.narrowtex.com.au)